



User Manual

Code Blue

Special Module for Receiving Signal



Scan the QR code or enter following URL to get the latest version:
<https://docs.mobatime.cloud/CB>

Important Notes

1. Please read and follow the safety information in this document before operating the product. We cannot guarantee that no accidents or damage will occur to improper use of this product. Please use this product with care and operate at your own risk.
2. We are not liable for any direct or indirect damage caused by the use of this document or the said product.
3. This product must be connected and installed by qualified electrician who is familiar with the relevant regulations (e.g. VDE).
4. The information in this document is subject to change without notice. The latest version of this document is available for download at <https://docs.mobatime.cloud/CB/user-manual/pdf> .
5. This User Manual has been composed with the utmost care to explain all the details to ensure a safe and stable operation of this product. Nevertheless, if question arise or error appear, feel free to contact support.
6. Images shown are for illustrative purposes and may differ from the final product.
7. No part of this document or the said product may be reproduced in any form or by any means or used to make any derivative such as translation, transformation, or adaption without permission from ELEKON, s.r.o., Brněnská 364/17, Vyškov 682 01 / CZECH REPUBLIC.
8. Copyright © 2026 ELEKON, s.r.o., Brněnská 364/17, Vyškov 682 01 / CZECH REPUBLIC. All rights reserved.

Table of Contents

- 1. **Introduction** 5
- 2. **Connection to the Digital Clock** 6
- 3. **Recommended Digital Clock Settings** 7
- 3.1. Configuration Procedure 7


1 Introduction

The Code Blue module is an optional module for MOBATIME digital clocks designed to receive a Code Blue signal from an external system and to automatically activate a dedicated emergency stopwatch function on the clock display.


2 Connection to the Digital Clock

The Code Blue module is connected to the **TEMP** terminal block on digital clock PCB.


TEMP standard plug-in terminal block



TEMP plug-in terminal block



TEMP screw terminal block (directly on digital clock PCB)



3 Recommended Digital Clock Settings

To ensure correct operation of the Code Blue module, the digital clock must be set appropriately.

3.1. Configuration Procedure

1. Enter the digital clock main menu.
2. Navigate to the `SEOP` submenu and enter.
3. Set each menu item according to the table:

Menu Item	Value	Description
<code>h2</code>	<code>7</code>	Control mode 7
<code>h6</code>	<code>1</code>	External keyboard connected
<code>h8</code>	<code>1</code>	Input 1 active high (LOG1)
<code>10</code>	<code>1</code>	Display blink enabled
<code>11</code>	<code>5 - 50</code>	Blink period as needed
<code>12</code>	<code>10 - 90</code>	Blink duty as needed



*Headquarters/Production
Sales Worldwide*

Tel. +41 34 432 46 46 | Fax +41 34 432 46 99
moserbaer@mobatime.com | www.mobatime.com

Sales Switzerland

MOBATIME AG | Stettbachstrasse 5 | CH-8600 Dübendorf
Tel. +41 44 802 75 75 | Fax +41 44 802 75 65
info-d@mobatime.ch | www.mobatime.ch

MOBATIME SA | En Budron H 20 | CH-1052 Le Mont-sur-Lausanne
Tél. +41 21 654 33 50 | Fax +41 21 654 33 69
info-f@mobatime.ch | www.mobatime.ch

Sales Germany/Austria

BÜRK MOBATIME GmbH
Postfach 3760 | D-78026 VS-Schwenningen
Steinkirchring 46 | D-78056 VS-Schwenningen
Tel. +49 7720 / 85 35 - 0 | Fax +49 7720 / 85 35 - 11
buerk@buerk-mobatime.de | www.buerk-mobatime.de